

# **EAP-SIM**

## **Manual Configuration Guide**

### **for Windows Phone 8.1**




## 1 Connect to Wireless@SGx via EAP-SIM

---

- a) Select Wi-Fi from settings menu. Connect to Wireless@SGx SSID.



- b) From "Connect using" drop down menu, select "SIM". Make sure EAP method is "SIM AKA" and click done.



- c) Once connected, the menu will show “Secure” at Wireless@SGx connection.



---

## 2 Uninstall EAP-SIM profile

Follow the steps below to remove the configuration:

- a) Select Wi-Fi from settings menu.
- b) Search for **Wireless@SGx** profile in the list of Wi-Fi networks
- c) Press and Hold on the **Wireless@SGx** profile
- d) Confirm the removal of your profile by tapping the “**Delete**” option in the popup window