

## Wireless@SG EAPSIM Supported Handsets

1. The following models allows you to log in to EAPSIM automatically without configuration:

Blackberry	Sony	Samsung
Z10	Xperia Z Ultra	Galaxy Tab Pro 10.1
Q10	Xperia Z1	Galaxy Tab Pro 8.4
Q5	Xperia Z2	Galaxy S5
Z30	Xperia Z	
Curve 9320	Xperia T2 Ultra	
Bold 9720	Xperia M2	
Bold 9790	Xperia Z2 Tablet	
Bold 9900		
PD 9981		
Torch 9860		
Torch 9810		

LG	HTC	Asus
G Flex	HTC One (M8)	Fonepad 7 LTE
G 2		
G Pro2		
G2 Mini		

2. The following models require manual configuration for EAPSIM:

Samsung	Apple	Sony	HTC
Galaxy Note 10.1	iPhone 4	Xperia SP	One
Galaxy Ace 3	iPhone 4s	Xperia C	One Max
Galaxy Tab 3.8	iPhone 5	Xperia L	SV
Galaxy Note 3	iPhone 5c	Xperia ZL	Butterfly S
Galaxy Note 2 LTE	iPhone 5s	Xperia V	One Mini
Galaxy Note 3 LTE	iPad 2	Xperia M	Desire 601
Galaxy Tab 3 10.1	iPad 3rd Gen	Xperia Z1 Impact	
Galaxy S3 Activ	iPad 4th Gen		
Galaxy Tab 3 7.0	iPad 5th Gen		
Galaxy S III	iPad Mini		
Galaxy S4 LTE(CAT 4)	iPad Mini 2		
Galaxy Note 8.0 LTE			
Galaxy Tab 2 10.1			
Galaxy S4 Zoom			
Galaxy Mega 6.3 LTE			
Galaxy S4 Mini			
Galaxy S3 Mini			
Galaxy Express			
Galaxy Tab 2 10.1			
Galaxy Note 10.1" LTE			

*\*Please note that iOS handsets from iPhone 4 and iPad 2 onwards will be able to support automatic connection by May 2014*